




Inverted Head Post to Standard Bone or Tail Bone



LIFT AND LOCK CUSTOMIZATION ASSEMBLY GUIDE

How to make your Lift and Lock System better suit your needs.

COVER STICKER
6mm SCREW
6mm WASHER
SPRING WASHER
PTFE WASHER
STANDARD HEAD



To invert a Lift and Lock Head, the Head must be flipped upside down and attached with an Inverted Head Post

BUSHING



INVERTED HEAD POST



PTFE WASHER



STANDARD BONE



BUSHING



SPRING WASHER



6mm WASHER



6mm SCREW



Inverted Head Post to Standard Bone or Tail Bone